

# Performance Is Looming

## YB Cosworth ALS/LC Wiring Instructions

Thank you for purchasing our ALS/LC Wiring loom. We have made this loom as simple as possible to install.

If you have purchased the Loom with the OE plug connector, then very simply this will plug into the loom plug which on sierra models is by the ECU, or on Escort Models is in the engine bay behind the N/S strut top.

Those that have chosen to connect directly to the ECU, need to remove the ECU and remove the ECU connector cover, Using a terminal tool, remove the pins that are in place in pins 13 and 14, and replace them with our new wiring loom pins following the diagram below. This loom also requires you to make a ground contact on the brown wire which spurs from the new loom. Simply connect this to any ground.

Once this has been completed the loom can be neatly routed though the car, the switches can be mounted and connected.

The Launch Control ground wire can be connected to the handbrake light switch to allow handbrake activation of the Launch Control, this connector has a piggy back terminal fitted to allow the OE handbrake light switch to be reconnected once our loom has been plugged into the handbrake light switch.

ECU connection colour addition **White, pin 14, Yellow, Pin 13**

[If you have any problems or concerns, don't hesitate to call us. We are here to help.](#)